

Installation instructions for Fretlight Studio™ Software

New User (I don't have any previous Fretlight programs installed on my computer):

1. Download the Fretlight Studio zip file to your computer from the install CD you received with your guitar or from our website at www.fretlight.com.
2. Double-click the Install icon and follow the prompts. PLEASE BE PATIENT it's a large install, approx 71 mb.
3. The Fretlight Studio Software utilizes Microsoft's .net 1.1 framework. If your computer does not have .net already installed you will be prompted during installation of the Fretlight Studio to install it. You MUST have .net 1.1 installed so click yes to the install. NOTE: Even if you have a higher version of .net installed, you still need version 1.1 installed. Don't worry, it can exist side-by-side your higher version just fine.
4. When the install is finished a Fretlight Studio icon should appear on your desktop (unless you indicated during the install not to have one created). Double click the Studio icon to launch the program.

Existing User (I already have some Fretlight programs on my computer):

1. Uninstall the following programs on your computer – M-Player, Improviser, Lesson Player and Video Player. Restart your computer.
2. Follow the Fretlight Studio install instructions above.
3. You will need to move your M-Player songs from their current location to the "songs" folder in the Fretlight Studio directory
4. You will need to re-install any Lesson Paks or Style Paks that you have purchased. If you no longer have the zip file download, go to your account on www.fretlightstore.com and re-download them.
5. If you have any questions please email or call us at support@fretlight.com or 1-800-575-6511.

Optek Music Systems, Inc.

www.fretlight.com